

	PART NO.	DESCRIPTION	PRICE
PUSH BUTTONS AND ACCESSORIES			
	G303	AF3 GREEN PUSH BUTTON 30MM	R 66.00
	G304	AF4 RED PUSH BUTTON	R 66.00
	G322	AS2-2P 2-POSITION SELECTOR SWITCH 30MM	R 170.00
	G311	S11 CONTACT BLOCK	R 86.00
	G312	S12 CONTACT BLOCK 1N/O 1N/C	R 165.00
	G600	P9XPNVG GREEN PUSH BUTTON	R 74.00
	G601	P9XPNRG RED PUSH BUTTON	R 74.00
	G602	P9XPNGG BLACK PUSH BUTTON	R 74.00
	G603	P9XPNGG YELLOW PUSH BUTTON	R 74.00
	G604	P9XPNLG BLUE PUSH BUTTON	R 74.00
	G605	P9XEM4RN MUSHROOM MOMENTARY PUSH BUTTON	R 117.00
	G606	P9XER4RN MUSHROOM TWIST	R 145.00
	G607	P9XET4RL1 MUSHROOM ILLUMINATED PUSH-PULL 40MM	R 195.00
	G610	P9XSMDON 2-POSITION SELECTOR SWITCH	R 126.00
	G611	P9XSMZON 3- POSITION SELECTOR SWITCH	R 130.00
	G612	P9XSMD5N 2-POSITION SPRING RETURN SELECTOR SWITCH	R 162.00
	G613	P9XSMZ3N 3-POSITION SPRING RETURN SELECTOR SWITCH	R 152.00
	G615	P9XSCDOK95 2-POSITION KEY SWITCH	R 160.00
	G616	P9XSCZ0T95 3-POSITION KEY SWITCH	R 244.00
	G617	P9XSCI5C95 2-POSITION SPRING RETURN KEY SWITCH	R 286.00
	G618	P9XSCZ3C95 3-POSITION SPRING RETURN KEY SWITCH	R 244.00
	G620	P9DPLVRG00 DOUBLE PUSH BUTTON	R 116.00
	G622	P9XPL*GD ILLUMINATED PUSH BUTTON HEAD ONLY	R 92.00
	G648	ENGRAVED LEGEND PLATE	R 22.00
	G649	080XTGR02 EMERGENCY STOP ROUND PLATE	R 23.00
	G650	P9B10VN 1N/O CONTACT BLOCK	R 42.00
	G651	P9B01VN 1N/C CONTACT BLOCK	R 42.00
	G652	P9B20VN 2NO CONTACT BLOCK	R 93.00
	G654	P9B02VN 2N/C CONTACT BLOCK	R 93.00
	G662	P9B11VN 1N/O 1N/C CONTACT BLOCK	R 85.00
	G664	P9B10VA N/O EARLY CLOSING	R 87.00