

	PART NO.	DESCRIPTION	PRICE	
PUSH BUTTONS AND SWITCHES				
	L600	MS-FB-GN GREEN PUSH BUTTON	R	62.00
	L601	MS-FB-RD RED PUSH BUTTON	R	62.00
	L602	MS-FB-BK BLACK PUSH BUTTON	R	62.00
	L603	MS-FB-YW YELLOW PUSH BUTTON	R	62.00
	L604	MS-FB-BE BLUE PUSH BUTTON	R	62.00
	L605	MS-EB4 MUSHROOM PUSH MOMENTARY	R	62.00
	L606	MS-EB4T MUSHROOM PUSH BUTTON TWIST RELEASE	R	85.00
	L610	MS-SL20 2-POSITION SELECTOR SWITCH	R	65.00
	L611	MS-SL30 3-POSITION SELECTOR SWITCH	R	75.00
	L612	MS-SL21 2-POSITION SELECTOR SWITCH SPRING RETURN	R	65.00
	L613	MS-SL31 3-POSITION SELECTOR SWITCH SPRING RETURN	R	75.00
	L615	MS-KS20 2-POSITION KEY SWITCH	R	75.00
	L616	MS-KS30 3-POSITION KEY SWITCH	R	85.00
	L617	MS-KS21 2-POSITION KEY SWITCH SPRING RETURN	R	75.00
	L618	MS-KS33 3-POSITION KEY SWITCH SPRING RETURN	R	85.00
	L619	MS-KS34 3-POSITION KEY SWITCH SPRING RETURN	R	85.00
	L620	MS-CB2 DOUBLE PUSH BUTTON	R	75.00
	L622G	MS-IL-G GREEN ILLUMINATED PUSH BUTTON	R	85.00
	L622R	MS-IL-G RED ILLUMINATED PUSH BUTTON	R	85.00
	L622Y	MS-IL-Y YELLOW ILLUMINATED PUSH BUTTON	R	85.00
CONTACT BLOCKS				
	L650	MS-01 1N/O CONTACT BLOCK	R	18.00
	L651	MS-02 1 N/C CONTACT BLOCK	R	18.00
	L665	ZBV-6 LAMP HOLDER	R	12.00